




TOP AND CONSOLE PARTS

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)

GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3977703	Literature Parts Label, Wiring Diagram	8	8271359	Cap, End (R.H.) White	24	8271399	Top White
	LIT8314842	Guide, Use & Care		8271362	Biscuit		8271401	Biscuit
	LIT3405344	Instructions, Installation	9	8271316	Bracket, Control	25	3405154	Switch, Finish Guard
Following May Be Purchased			10	3390646	Screw, 8-18 x 5/16	26		Cap, End (L.H.)
DO-IT-YOURSELF REPAIR MANUALS			11	3401850	Harness, Gas		8271365	White
	LIT677818	Manual, Do-It-Yourself Repair (Dryer)	12	388326	Screw, Console		8271368	Biscuit
2	3976705	Panel, Rear Console	13	3405155	Switch, Temp.	27	3936144	Connector
3	3406725	Timer	14	3391018	Tie, Cable (Push-Mount)	28	3403498	Connector, 3-Position (Gas Valve)
4	3400859	Screw, Grounding (8-18 x 7/32)	15		Knob, Control	29	3390537	Control, Electronic
5	3398095	Relay, Push-To-Start		8271399	White	30	694419	Buzzer, Mini
6	3391885	Connector, Edge		8271348	Biscuit	31	3978112	White
7	3395683	Connector (Motor)	16	3397269	Connector, Timer		3978113	Biscuit
			17	717252	Receptacle, 2-Way	34	697779	Plug, 3-Way
			18	3403499	Connector, 2-Position (Gas Valve)	35	3390647	Screw, 8-18 x 1/2
			19	8299920	Harness, Wiring	37	3401144	Connector (PTS Relay)
			20		Timer Knob Assembly	40	351296	Receptacle
				8312687	White	41	3394427	Clip, Harness
				8271404	Biscuit	44	94614	Terminal
			22	387402	Hinge, Assembly			
			23	357213	Nut, Push-In (2)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3387680	Cover, Terminal Block	18	233520	Washer, Thrust	48	694091	Screw, 8-18 x 3/8
2	3390814	Screw, 8-18 x 3/8	19	297092	Clip (2)	49		Door, Front
3	3390647	Screw, 8-18 x 1/2	20	690997	Tri Ring		697221	White
4	3394331	Plate, Cover	21	3387560	Hinge, Door (R.H.)		3977763	Biscuit
5	3394881	Switch, Broken Belt		3387559	Hinge, Door (L.H.)	50	691581	Lever, Door
6	344020	Cord, Power	22	3387565	Spring, Door (2)			Switch
7		Cabinet	23	3391408	Lever, Snap Switch	51		Upper Front Panel
	3402264	White	24	3394081	Wire, Belt Switch		697227	White
	3977765	Biscuit	25	49026	4" - 90° Elbow		3977761	Biscuit
8	3392100	Foot, Dryer	26	3393657	Restrainer, Belt	52	696144	Strike, Door
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	27	3395654	Motor, Assembly 60 HZ.	57	3390736	Seal, Door
9	660658	Clamp, Motor (2)	28	3395534	Exhaust Pipe (Short)	58	690081	Catch, Door
10	3387374	Spring, Idler	29	3389729	Pulley 60 HZ.	60	690270	White
11	3389420	Retainer, Idler	30	661570	Belt, Drive		3977242	Biscuit
12		Plug, Multivent	31	693152	Bumper	61		Toe, Panel
	697750	White	32	3387118	Bracket, Motor		697215	White
	3388311	Biscuit	33	3395535	Exhaust Pipe (Long)		3977764	Biscuit
13	3388672	Pulley Assembly	34	3388600	Clip, Lint Duct	Optional Parts Not Included		
14	3390663	Screw, 10-16 x 1/2	35	98129	Screw, 6-20 x 1 3/8	Dryer Exhaust Kit (For Side & Bottom Venting)		
15	697776	Screw, Ground	36	693995	Screw, 8-18 x 3/8			
16	3398948	Wire, Jumper (Broken Belt Switch)	39	3388674	Idler Bracket			
17	3395532	Exhaust Pipe & Bracket	40	3357011	Screw, 10-16 x 1/2			
			41	3392266	Switch, Door			
			44	3387242	Seal, Front Panel	62	279818	White
			46	3388229	Retainer		279925	Biscuit
			47	8066045	Door, Rear			

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
4392901 Biscuit
350938 Primer, Gray


PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit(Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread	17	3387809	Bulkhead, Rear	43	3403140	Thermostat,
2	3390647	Screw, 8-18 x 1/2	18	3387459	Washer, Support			High-Limit 205°F
3	90767	Screw, 8-18 x 3/8	19	3399509	Shaft, L.H. Thread			(96°C)
4	3394986	Spring, Lint	20	690997	Ring, Tri	44	697363	Housing, Blower
		Screen Door	21	3396801	Roller, Support	45	3390531	Lint Duct Assembly
5	3394346	Air Duct Assembly	23	3394985	Outlet Housing	46	8066047	Funnel, Burner
6	697813	Seal, Outlet			Assembly	48	338906	Sensor, Radiant
		Housing	25	697282	Complete Drum	51	3387230	Screw, 10-16 x 1
7	697814	Seal, Drum Front			Assembly	52	697771	Cover, Blower
8	3359452	Nut, 3/8 x 16(R.H.)	26	97787	Screw, 11-16 x 3/4			(Includes Illus.
9	3977358	Drum Hole	27	697694	Seal, Drum			No. 62)
		Plug	30	3395536	Clip, Exhaust	53	697693	Baffle, Drum
11	3406931	Light Socket			Pipe	54	697563	Bulkhead, Front
		Assembly	34	3387223	Electrode, Sensor	58	8299979	Grill, Outlet
13	3392258	Ground-Sensor	35	3395196	Lens, Drum	59	3390719	Thermal Fuse
14	3394984	Door, Lint			Light	60	697770	Seal, Cover Plate
		Screen	36	3406125	Lamp,	62	697769	Seal, Lint Duct
15	3402715	Exhaust Pipe			Incandescent	64	3390721	Lint, Screen
		Assembly	37	697772	Wheel, Blower	65	487909	Screw, 8-18 x 1/2
		(Includes Illus.	38	3406907	Bracket, Lamp			
		No. 30)	42	3977706	Thermostat,			
16	3387709	Nut, 3/8-16 (L.H.)			Internal Bias			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402851 BURNER ASSEMBLY

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402851 BURNER ASSEMBLY

For Models: GGQ8858JQ0, GGQ8858JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3402851	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	660991	Ignitor 686590 (Alt)
5	3393909	Screw & Washer (8-32 x 5/8)
6	697775	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8 (3)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, Gas 60 Hz. (Complete)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	3387224	Pipe, Gas Supply
22	3406051	Elbow Union Assembly
23	233077	Pipe, Tail
24	233076	Nut, Compression
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1, 2 & 3)
to Type (4) L.P.G.

BA-143 A